February 21, 2019

Version 1.0

SCOPE OF TECHNICAL SPECIFICATIONS

TABLE OF CONTENTS

	TECHNICAL SPECIFICATION					
ID	Topic Name	Page				
1	DEFINITIONS	1				
2	GENERAL REQUIREMENTS [E]	2				
3	DOPPLER VHF OMNI-DIRECTIONAL RADIO RANGE EQUIPMENT (DVOR) [E]	5				
4	DISTANCE MEASURING EQUIPMENT (DME) [E]	8				
5	CONTROL AND MONITORING [E]	11				
6	INTERSYSTEM CONNECTION	14				
7	SUPPLEMENTS	14				
8	TOOLS FOR INSTALLATION AND MAINTENANCE	16				
9	TECHNICAL DOCUMENTS AND TEST REPORTS [E]	16				
10	DESKTOP COMPUTER	17				
11	CONCEPTUAL DIAGRAM OF INTERSYSTEM CONNECTION AND COMMUNICATION	19				
12	APPENDIX A: LIST OF ABBREVIATIONS	20				
13	APPENDIX B: Figure C-20	22				
14	APPENDIX C: Location	23				
15	GUIDELINE FOR "Bill of Materials and Services"	24				
16	Attachment (11 Pages)	27				

1. DEFINITIONS

In the specification, the following words and expression shall have the meanings assigned to them here under except where the context otherwise requires:

AEROTHAI	Aeronautical Radio of Thailand Ltd.
Essential requirement	Essential requirement specification which is mandatory requirement by
specification [E]	which the Tenderer shall fully comply with AEROTHAI's requirement
	stipulated in Scope of Specifications. The Proposal will be rejected if the
	proposed system, functions of features fail to comply with Essential
'	requirement specification.
Proposal	The response to the requirement specified in Scope of Specifications.
Tenderer	The juristic person, firm or company who offers to provide materials or
	perform a service or do a job with AEROTHAI at a specified cost or rate.
Contractor	The juristic person, firm or company whose Tender(s) /Proposal(s) has/have
	been accepted by AEROTHAI and who agrees to accomplish the activities
	for AEROTHAI.
ICAO Annex 10 Vol. I	Aeronautical Telecommunications: Volume I Radio Navigation Aids.
	Seventh Edition, July 2018, Amendments 91.
ICAO Annex 14 Vol. I	Aerodromes: Volume I Aerodrome Design and Operations.
	Eighth Edition, July 2018, Amendments 1-14.
ICAO Doc 8071 Vol. I	Manual on Testing of Radio Navigation Aids: Volume I, Testing of Ground-
	Based Radio Navigation Systems. Fifth Edition – 2018.

2.	GEN	IERAL REQUIREMENTS [E]					
	2.1	The Project consists of DVOR/DME systems as the following:					
		2.1.1 One (1) DVOR/DME Systems shall be installed at Betong Airport.					
		2.1.2	Monitor antenna of DVOR shall be installed at Counterpoise edge by contractor that follow the manufacturer installation manual.				
		2.1.3	Cable ladders shall be provided and installed by contractor				
	2.2		VOR/DME Systems shall be designed based on dual transmitters and dual monitors uration which consists of the following:				
		2.2.1	Dual DVOR Equipment;				
		2.2.2	Dual DME/N Equipment;				
		2.2.3	Antenna Systems for the above equipment;				
		2.2.4 Local Control Unit (LCU) of DVOR and DME include its local computer a DVOR/DME station, as specified in [5.1-5.2].					
		2.2.5 Remote Control and Status Unit (RCSU) for the above equipment specified in 2.2.2 which shall be equipped at Technical Control Room in ATC Tower; as spe in [5.3].					
		2.2.6	Remote Status Unit (RSU) for the above equipment specified in 2.2.1-2.2.2 which shall be equipped at ATC Tower; as specified in [5.4].				
		2.2.7	Remote Maintenance and Monitoring (RMM) Equipment (Computer) for the above equipment specified in 2.2.1-2.2.2 which shall be equipped at Technical Control Room in ATC Tower, as specified in [5.5].				
	2.3	The D	VOR/DME systems shall have SNMP management capability are specified in clause 6.				
	2.4	1	vstem performance and its signal-in-space quality shall at least comply with the ICAC 10 Vol. I.				
	2.5	All RF	Generators shall be synthesizers.				
	2.6	i	quipment shall be the modular design, or an easy plug-in card or modules for quick ement with the purpose for easy maintenance and repair.				
	2.7	The dual independent transmitters shall be housed in the cabinet (s) and operated as mai and standby facilities. Maintenance on one equipment shall be accomplished without disruption the operation of the others.					
	2.8	The e	quipment shall be designed in common of modules and printed circuit boards.				
	2.9	The MTBO of each system shall be greater than 10,000 hours. The Tenderers shall submit reliability analysis (MTBF, MTBO) in the Proposal.					

2.	.10	The D	ME equipment shall be installed in co-location with the DVOR equipment.							
2.	.11	Each L	ine Replaceable Units (LRU) of DVOR/DME Equipment shall be easily exchangeable.							
2.	.12 I	Indoor equipment shall be designed for continuous operation at least under the ambient								
	t	temperature range of 0 °C to +50 °C with a relative humidity of up to 95%.								
	į.	Outdoor equipment shall be designed for continuous operation at least under the								
	t	tempe	rature range of -40 $^{\circ}\mathrm{C}$ to +60 $^{\circ}\mathrm{C}$ with a relative humidity of up to 100%, up to 100							
	r	mph (160 Km/h) wind velocity.							
:	i		tdoor materials shall be suitably weather protected by appropriate coat or high grade							
	ķ	oaint	in order to withstand severe ambient conditions of outdoor installation due to							
	t	empe	rature, humidity, rainfalls, as specified in ICAO Annex 14 Vol. I.							
2	.13	AC/DC	power lines, transmission lines, control lines, test cables and all relevant accessories							
	5	shall b	e as follows:							
	2		All AC/DC power lines, transmission lines, control lines and relevant accessories (e.g.							
			connectors, cable trays, conduits and cable ties) shall be provided by the contractor.							
			The transmission line shall be the rodent protection type. If the installation work							
			involves buried cables, they shall be "underground-type" and fitted in HDPE or							
			RSC pipes which the inner diameter shall be wide enough for fitting all cables easily;							
	2	2.13.2	All transmission lines shall be laid in a different pipe separated from that of AC power							
			lines;							
	2.13.3 The underground cable work shall be done by the Contractor. The tren									
			underground cable shall be dug with more than fifty (50) cms in depth from ground							
			surface and not less than thirty (30) cms in width. The trench basement shall be							
			covered with twenty (20) cms thick of sand which is the base of underground cable.							
			Finally, the underground cable shall be covered with twenty (20) cms thick of sand							
			topping with twenty (20) cms thick of soil;							
	2	2.13.4	All known power and control lines (or else cable routes) leading to the facility shall							
			be marked out by the contractor;							
	2	2.13.5	Cable route markers shall be installed at every 10 meters for indicating underground							
			cables. The cable route marker specifications are detailed in section 2: Counterpoise							
			and Grounding System Requirements;							
	2	2.13.6	The Contractor shall take all responsible precautions to protect existing underground							
			equipment and utilities;							
	2	2.13.7	The Contractor shall provide all external RF connectors type and model that							
			complied with IEC61169 or other international standards.							

2.1	4 Power	er supply						
	2.14.1	The DVOR/DME System shall be operated with 230 VAC \pm (\geq 10%), 50 Hz \pm (\geq 2%).						
	2.14.2	1.2 Power supply module for DVOR and DME equipment shall be individually supplied.						
2.1	5 Lightni	ightning protection, surge protection system shall be as follows.						
	2.15.1	All above system must be complied with IEC-62305 international standard or other						
		international standards.						
	2.15.2	The tenderer shall submit brand, model and the related document of lightning						
		protection system in the proposal Including						
		- Air-Termination System.						
		- Down Conductor System.						
		- Lightning Arrester, the so-called "Surge Protective Device (SPD)".						
		The lightning protection system shall be installed and connected to existing						
		station grounding system which is installed by AEROTHAI (see detail in						
_		Attachment Page 28 - 38)						
	2.15.3	The lightning protection system shall adequately protect all of the DVOR/DME and						
		peripheral equipment in the event of a lightning strike.						
<u> </u>		The surge protection for all Telecom line shall be provided.						
	2.15.5	The Contractor shall supply RF Coaxial cable surge protection for VOR band and						
-		DME band complied with IEC-62305 or other international standards.						
		tal resistance of the grounding system shall not exceed 5 Ω						
2.1	i	ackup battery with charger unit for DVOR/DME equipment shall also be included in wer supply system.						
2.1	8 The k	packup battery shall have sufficient capacity to enable to operate at least						
	Three	(3) hour in the event of an AC mains failure.						
2.1	9 Equipm	nent Warranty						
	2.19.1	Minimum 5 years warranty as follows:						
		2.19.1.1 DVOR/DME Equipment and spare parts.						
		2.19.1.2 Lightning Protection and Surge Protection System.						
		2.19.1.3 PNSA and Tools for installation and maintenance.						
	2.19.2	Minimum 2 years warranty as follows:						
		2.19.2.1 Computer and its Accessories.						

		As conform to detail in non technic TOR item No.14 (เอกสารประกวดราคาจัดซื้อข้อ เรื่องการประกันความชำรุดบกพร่อง)							
3.	DOF	PPPLER VHF OMNI-DIRECTIONAL RADIO RANGE EQUIPMENT (DVOR) [E]							
_	3.1	System Accuracy							
		3.1.1 Azimuth accuracy shall be better than ±1 degree on ground measurement.							
		3.1.2 Azimuth stability shall be better than ±0.5 degree measured at a mon							
	3.2	The dual DVOR equipment shall comprise, but not limited to:							
		3.2.1	Dual carrier transmitters;						
		3.2.2	2.2 Dual sideband transmitters;						
		3.2.3	Dual m	onitors;					
		3.2.4	DVOR to	est generator;					
		3.2.5	Antenn	a Switching Unit;					
		3.2.6	Antenn	a System.					
	3.3	Carrie	r Transm	nitter					
		3.3.1	Freque	ncy band	- 108 MHz to 117.975 MHz				
		3.3.2	Operati	ng frequency	- 113.10 MHz for Betong Airport				
		3.3.3	Freque	ncy stability	$-\pm0.002\%$ from the operating frequency				
		3.3.4	Output	power	- at least 100 watts (adjustable)				
		3.3.5	Carrier	modulation:					
			3.3.5.1	Reference frequency	- 30 Hz ± 0.2%				
			3.3.5.2	Modulation depth	- 30% (adjustable)				
			3.3.5.3	Identification frequency	- 1020 Hz ±50 Hz				
			3.3.5.4	Identification modulation Depth	- 10% (adjustable)				
			3.3.5.5	Speech channel filter	- band pass at the range of 300 to 3000 Hz within 3 dB relative to the level at 1000 Hz				
			3.3.5.6	Speech modulation depth	- up to 30% (the transmission of speech shall not interfere in any way with basic navigation function (adjustable)				
		3.3.6	}	ntification unit shall be abl Code for both DVOR and DM	e to generate any three letters Internationa				
		3.3.7	The set	ting up of DVOR Identification	on code shall be computerized.				

	3.3.8	The DM cycle.	IE Identification shall be generated on every forth DVOR Identification				
	3.3.9 Protection shall be provided for the RF amplifier from damage caused by or short circuit of the output. 3.3.10 One (1) set Thruline (line section) with plug-in element shall be equipped power output of the transmitter. One (1) RF Wattmeter shall be provided power reading. Type, model and diagram shall be submitted in the Proposition (line section) with plug-in elements shall be housed in the cabine						
3 4	Sideh	and Tran					
7.4	 `	1	e-sideband DVOR equipment shall be provided.				
	· .		p-carrier modulation mid-frequency shall be 9960 Hz ±1%.				
	 	 	ontrol circuit shall maintain phase stability between the sidebands and car				
	3.4.4	at each At least Type, m) sets Thrulines (line sections) with plug-in elements shall be equipp RF power output of the transmitters. Four (4) set of RF Wattmeter shall be provided for RF power reading and diagram shall be submitted in the Proposal.				
3.5	Monit	Thrulines (line sections) with plug-in elements shall be housed in the cabi					
J.J		The DV detection	OR Monitor system shall be capable continuous monitoring fault on and producing alarm signal (s) for the following conditions occurs: A change in excess of 1 degree of the bearing information transmitt				
		3.5.1.2	by the DVOR equipment; Reference signal 30 Hz modulation depth exceeds ±2% from to nominal value;				
		3.5.1.3	Sub-carrier 9960 Hz modulation depth exceeds ±2% from the nominal value;				
		3.5.1.4	Sub-carrier 9960 Hz deviation ratio exceeds 16 ±1.				
	3.5.2	The bea	aring alarm limit shall be adjustable with the step of not more than				
	3.5.3	The carrier RF level alarm limit shall be adjustable when the carrier level decreases at least 20 - 50% from the nominal value.					

		3.5.4	The ide	ntification alarm shall be provided for the following conditions:				
			3.5.4.1	Continuous keyed;				
			3.5.4.2	Loss of identification.				
		3.5.5	The Monitors shall be configurable such that both monitors are monitoring the					
			operating (on-antenna) or standby (on-dummy) transmitter simultaneously.					
		3.5.6	When t	wo Monitors are monitoring the operating transmitter, the Monitors can be				
			configur	ed either in 'AND' mode or 'OR' mode for a changeover or shutdown in the				
			event o	f failure.				
		3.5.7	The Mo	nitor shall provide a maintenance warning alarm to permit corrective action				
				an out-of-tolerance condition occurs. The warning indication shall be				
			, .	d at the designated control points and Remote Control and Status Unit				
			(RCSU).					
		3.5.8	•	rameters of DVOR Transmitter and Monitor shall be provided and show				
		İ	· ·	ay. Control and Selection for display of those parameters shall be done				
			1	nputerization which is permanently located at site. The following				
				ters, including but not limited to, shall be available:				
	ļ			The bearing information;				
				Reference signal 30 Hz modulation depth;				
-	ļ			Sub-carrier 9960 Hz modulation depth;				
				Sub-carrier 9960 Hz deviation ratio;				
				Identification;				
ļ		1		Forward and reflected power or standing wave ratio.				
<u> </u>				elay shall be adjustable.				
				istory shall be provided to identify the parameter that has deviated beyond				
ļ				m limit and caused the alarm.				
		3.5.11		difficult terrain at Betong Airport, At least two (2) Counterpoise edge Monitor				
				g RF surge protection) shall be provided for installation on the top of				
		l i	counterpoise edge that is monitoring the radiated composite signal.					
			Monitor type, and model shall be submitted in the Proposal.					
	3.6		enerator					
		3.6.1		t Generator for DVOR equipment shall be able to check and calibrate				
<u> </u>				nitor to conform with ICAO Annex 10 Vol. I.				
				nd model of the Test Generator shall be submitted in the Proposal				
			(in case	of separated unit).				

_		··							
		3.6.3			nostics shall be provided for all Lowest				
		ļ	.L		ble of being initiated locally and remotely.				
<u>_</u>	3.7	Anten	Antenna Switching						
		3.7.1	3.7.1 The RF Power Distributor in the Antenna Switching unit shall be broadband for						
			operation in the range of 108 MHz to 117.975 MHz.						
		3.7.2	Surge ar	nd Lightning Arrestors shall b	pe provided for all output ports of the distributor.				
	3.8	Anten	na Syste	m					
		3.8.1	The ope	rating frequency of each Ant	tenna element shall be adjusted from the factory.				
		3.8.2	The me	thod of sideband feed lines	fabrication and any other adjustment procedures				
			shall be	described in DVOR/DME in	stallation and equipment instruction manuals				
			(in claus						
		3.8.3	The Ant	e Antenna VSWR shall not exceed 1.2 : 1 for carrier and 1.2 : 1 for sideband.					
		3.8.4	8.4 The Antenna System shall provide sufficient coverage as required in ICAO Annex 10						
			Vol. 1 Paragraph 3.3.4 except where topographical features are dictated.						
4.	רצום	TANCE	E MEASURING EQUIPMENT (DME) [E]						
	4.1	The D	DME equipment shall comprise:						
		4.1.1	Dual tra	Dual transponders;					
		4.1.2	Dual mo	onitors;					
	<u></u>	4.1.3	Antenna	system.					
	4.2	Transp	onder						
		4.2.1	Frequen	cy band -	960 MHz to 1,215 MHz				
		4.2.2	Operatir	g channel -	CH 78X for Betong Airport				
		4.2.3	Transmit	ter characteristics					
			4.2.3.1	The radio frequency of op-	eration shall not vary more than \pm 0.002% from				
				the assigned frequency.					
			4.2.3.2	Pulse shape and spectru	m of pulse modulated signal shall meet the				
				requirements for DME/N in	n ICAO Annex 10 Vol. I Paragraph 3.5.4.1.3. and				
				3.5.5.1.3					
			4.2.3.3	Pulse spacing shall meet th	ne requirements specified in ICAO Annex 10 Vol.				
				Paragraph 3.5.4.1.4.					
			4.2.3.4	The peak power of constitu	uent pulses of any pair of pulses shall not differ				
				by more than 1 dB.					
			4.2.3.5	The power amplifier of th	ne transponder shall provide full peak output				
				power of not less than 1	.000 watts to the antenna.				

		4.2.3.6	DME equipment shall provide/embed the coupling port for measuring peak
			output power (External tool) without shutdown/turn OFF the equipment.
		4.2.3.7	Dead time, short distance echo suppression and long distance echo
			suppression shall be adequately adjustable for each DME station installed,
			in order to prevent any undesired signal degrading the system performance.
		4.2.3.8	The transmitter shall operate at a transmission rate, including randomly
			distributed pulse pairs and distance reply pulse pairs, of not less than 700
			pulse pairs per second except during identity.
			Note.— Operating DME transponders with quiescent transmission rates close to 700
			pulse pairs per second will minimize the effects of pulse interference, particularly to
	<u> </u>		other aviation services such as GNSS.
		4.2.3.9	The maximum transmission rate shall be at least 4800 PPS.
		4.2.3.10	Identification shall meet the requirements specified in ICAO Annex 10 Vol.
			Paragraph 3.5.3.6 for association with the DVOR identification.
	4.2.4		characteristics
		4.2.4.1	The centre frequency of the receiver shall not vary more than ±0.002% from
			the assigned frequency.
		4.2.4.2	Interrogation pulse pairs with correct spacing and nominal frequency
			shall trigger the transponder if the peak power density at the
			transponder antenna is at least -103 dBW/m2 and this value cause the
		*	transponder to reply with an efficiency of at least 70% complies with in
			ICAO Annex 10 Vol. Paragraph 3.5.4.2.3.1, 3.5.4.2.3.2, 3.5.4.2.3.5 and
<u> </u>			3.5.5.3.2.1.
		4.2.4.3	Bandwidth and selectivity shall meet the requirements specified in ICAO
		 	Annex 10 Vol. Paragraph 3.5.4.2.6.
		4.2.4.4	CW and echo suppression shall be provided and meet the requirements
			specified in ICAO Annex 10 Vol. I Paragraph 3.5.4.2.9.
		4.2.4.5	DME/N-Decoder rejection. An interrogation pulse pair with a spacing of
			\pm 2 μs or more, from the nominal value, shall be rejected and meet the
			requirements specified in ICAO Annex 10 Vol. I Paragraph 3.5.4.3.3
		4.2.4.6	Receiver dead time shall be adjustable for echo suppression as measured
			after main delay time.
	4.2.5	Time Del	lay
		4.2.5.1	The time delay shall meet the requirements specified for DME/N in ICAO
			Annex 10 Vol. Paragraph 3.5.4.4.

			4.2.5.2	Reply delay, pulse spacing and pulse width shall be adjustable to the				
				specified values without removing any module from the assembly.				
	4.3	DME Monitor						
		nitor shall serve two purposes.						
			4.3.1.1	To ensure that the transponder signal is within the tolerance as specified for				
				DME/N in ICAO Annex 10 Vol. I Paragraph 3.5.4.7.2				
			4.3.1.2	To be used as a Test signal generator in conjunction with a built-in test unit				
				for calibration, testing and maintenance of the transponder.				
		4.3.2		ised as ensuring the transponder signal within the tolerance [ANNEX 10 /				
ŀ				Paragraph 3.5.4.7.2]. The monitor system shall initiate an appropriate				
			"WARNIN	IG" or "ALARM" indication & sound if any related abnormal condition occurs.				
			4.3.2.1	Spacing error of transmitted pulse pair exceeds ± 1.0 µs				
			4.3.2.2	Reply delay error exceeds \pm 1.0 μ s for high powered DME.				
		<u></u>	4.3.2.3	Transmitting pulse count (Pulse Repetition Frequency) falls below 700 pps.				
			4.3.2.4	Continuous or loss of identification.				
			4.3.2.5	A fall of 3 dB or more in transmitted power output				
			4.3.2.6	A fall of 6 dB or more in the minimum transponder receiver sensitivity				
				provided that this is not due to the action of the receiver automatic gain				
				reduction circuits.				
		4.3.3	ŀ	currence of primary alarm shall initiate a transfer action while the main				
			nder is operating (on-antenna) and a shutdown action while the standby					
			1 .	nder is operating (on-antenna). The primary alarms are generated by				
			+	ting pulse spacing error (in 4.3.2.1) or reply delay error (in 4.3.2.2).				
		4.3.4		nitors shall be configurable such that both monitors are monitoring the				
		operating (on-antenna) and standby (on-dummy) transponder simultaneously.						
		4.3.5 When two Monitors are monitoring the operating transponder, the mo						
				gured either in 'AND' mode or 'OR' mode for a changeover or shutdown in				
				nt of failure.				
		4.3.6		story shall be provided to identify the parameter that has deviated beyond				
		ļ <u>-</u> -		n limit and caused the alarm.				
		4.3.7	1	nal generator output shall be selected, The channel frequency deviation of				
<u> </u>				Hz and ± 900 kHz of the transponder receiver can be tested.				
		4.3.8		nal generator (interrogation) output level shall be adjustable at least from-91				
		<u></u>	dBm to	-20 dBm at the transponder antenna connector.				

	4.3.9	4.3.9 Test signal generator PRF shall be adjustable nearly 700 to at least 4800 PPS.				
	4.3.10	At least	the following Transponder and Monitor parameters shall be available for			
		display at the designated control points:				
		4.3.10.1	Reply delay;			
		4.3.10.2	Reply pulse pair spacing;			
		4.3.10.3	Reply efficiency;			
		4.3.10.4	Transmit power;			
		4.3.10.5	Transmitter pulse count;			
		4.3.10.6	Identification.			
	4.3.11	Settings	and selection for display of the Transponder and Monitor parameters in			
		4.3.11 sh	all be done by a Desktop Computer (refer to 5.2.4. and 5.2.5)			
4.4	DME A	ntenna S	ystem			
	4,4.1	The radia	ation patterns of the Antenna System shall be submitted with the Tender.			
		For the I	horizontal radiation pattern, the antenna shall be Omni-directional type.			
		For the	vertical radiation pattern, The antenna main lobe shall be maximum at			
		three (3) degrees (see Figure C-20 of [ANNEX 10 / Vol. I / Attachment C / Paragraph				
		7.2.1]) in Appendix B.				
	4.4.2	The Ante	enna shall be capable of radiating DME signal throughout the DME frequency			
		band (96	50 MHz to 1,215 MHz) so that changing of the operating frequency needs no			
	<u> </u>	readjustr	ment of the Antenna.			
	4.4.3	The ante	enna gain shall <u>not</u> be less than +9 dBi .			
	4.4.4	One (1)	set Double LED obstruction lighting equipment with photo-switch shall			
		be insta	lled with the antenna. The LED obstruction lighting equipment shall			
		conform	to the ICAO Annex 14 Vol. I Chapter 6 – Visual Aids for Denoting			
		Obstacle	s or Federal Aviation Administration (FAA) Specification for Obstruction			
		Lighting	Equipment (AC150/5345-43F OR 43G). Type and model shall be			
		submitte	ed in the Proposal.			

5.	CON	CONTROL AND MONITORING [E]		
	5.1	DVOR	Local Co	ontrol Unit (LCU)
				OR equipment shall be able to operate on local or remote control. It shall least the following control and monitoring functions:
		-	5.1.1.1	Selecting the main;
			5.1.1.2	Turning on/off transmitter;

			<u> </u>	
			5.1.1.3	Turning on/off the standby transmitter into dummy loads for testing
	ļ			purposes;
	<u> </u>		5.1.1.4	Selecting Remote/Local Control;
			5.1.1.5	Resetting the alarm;
			5.1.1.6	Shutting down the station;
			5.1.1.7	Displaying operating status of the equipment;
			5.1.1.8	Bypassing the monitor.
		5.1.2	The DVC	OR Local Control Unit shall automatically transfer from the selected antenna
			to a star	ndby antenna and/or shut down in the event of an alarm.
		5.1.3	Reset fu	unction shall be provided to clear fault condition (s) and restart normal
			operatio	on.
		5.1.4	One (1) set of Desktop Computer shall be provided as part of the Local Control
			Unit for	DVOR. The Desktop Computer for DVOR shall be provided separately from
			the Desi	ktop Computer for DME. The Desktop Computer Specifications are specified
			in claus	e 10.
		5.1.5	The soft	ware for monitoring and controlling the DVOR equipment shall be installed
			in the D	esktop Computer. The recovery CD/DVD for the software shall be provided
			The use	r's license for the software shall be provided for AEROTHAI.
	5.2	DME L	ocal Cor	ntrol Unit (LCU)
		5.2.1	The DM	IE equipment shall be able to operate on local or remote control. It
			shall ha	ve at least the following control and monitoring functions:
			5.2.1.1	Selecting the main equipment;
			5.2.1.2	Turning on/off transponder;
			5.2.1.3	Turning on/off the standby transponder into dummy loads for testing
				purposes;
			5.2.1.4	Selecting Remote/Local control;
			5.2.1.5	Resetting the alarm;
			5.2.1.6	Shutting down the station;
· ·			5.2.1.7	Displaying the operating status of the equipment;
			5.2.1.8	Bypassing the monitor.
		5.2.2	 	1E Local Control Unit shall automatically transfer from the selected
				nder to a standby transponder and/or shut down in the event of an alarm.
		5.2.3		unction shall be provided to clear fault condition (s) and restart normal
			operatio	·
	L		1 1	

5.2.4 One (1) set of Desktop Computer shall be provided as part of the Local Control Unit for DME. The Desktop Computer for DME shall be provided separately from the Desktop Computer for DVOR. The Desktop Computer specifications are specified in clause 10. 5.2.5 The software for monitoring and controlling the DME equipment shall be installed in the Desktop Computer. The recovery DVD for the software shall be provided. The user's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitoring functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5.4 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.2 Turning on off transmitters/transponder; 5.5.2.3 Turning on off transmitters/transponder;				<u> </u>
Desktop Computer for DVOR. The Desktop Computer specifications are specified in clause 10. 5.2.5 The software for monitoring and controlling the DME equipment shall be installed in the Desktop Computer. The recovery DVD for the software shall be provided. The user's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitorin functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5.4 Remote Monitoring and Maintenance Equipment (RMM) The RMM Equipment shall monitor and control equipment by TCP/IP or better. The RMM Equipment shall monitor and control equipment by TCP/IP or better. The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder into dummy loads for standard provided in the standard transmitter/transponder into dummy loads for standard transmitter/transp		5.2.4	One (1)	set of Desktop Computer shall be provided as part of the Local Control
clause 10. 5.2.5 The software for monitoring and controlling the DME equipment shall be installed in the Desktop Computer. The recovery DVD for the software shall be provided. The user's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitoring functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.2. The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for the standay transmitter/transponder int			Unit for	DME. The Desktop Computer for DME shall be provided separately from the
5.2.5 The software for monitoring and controlling the DME equipment shall be installe in the Desktop Computer. The recovery DVD for the software shall be provided. The user's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitoring functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into dummy loads for turning on the standay transmitter/transponder into			Desktop	Computer for DVOR. The Desktop Computer specifications are specified in
in the Desktop Computer. The recovery DVD for the software shall be provided. The Juser's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitoring functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for the standay transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for turning on the standby transmitter/transponder into dummy loads for t			clause 1	0.
user's license for the software shall be provided for AEROTHAI. 5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitorin functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.5.4.2.3 Turn on/off switch for the status indicator. 5.5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for		5.2.5	The soft	ware for monitoring and controlling the DME equipment shall be installed
5.3 Remote Control and Status Unit (RCSU) 5.3.1 The DVOR/DME RCSU shall have at least the following control and monitorin functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.2 Trun on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for			in the De	esktop Computer. The recovery DVD for the software shall be provided. The
5.3.1 The DVOR/DME RCSU shall have at least the following control and monitorin functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for			user's lic	cense for the software shall be provided for AEROTHAI.
functions: 5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.2 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for	5.3	Remot	te Contro	l and Status Unit (RCSU)
5.3.1.1 Turn on/off the selected transmitter/transponder with indicator; 5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for		5.3.1	The DVC	DR/DME RCSU shall have at least the following control and monitoring
5.3.1.2 Transfer and shutdown with indicator; 5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 Turning on/off transmitter/transponder; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for			function	ns:
5.3.1.3 NORMAL/ALARM indicator and audible alarm; 5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for			5.3.1.1	Turn on/off the selected transmitter/transponder with indicator;
5.3.1.4 Alarm silence control with indicator; 5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave lin (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for			5.3.1.2	Transfer and shutdown with indicator;
5.3.1.5 Alarm reset. 5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.3 Turning on/off transmitters/transponder into dummy loads for			5.3.1.3	NORMAL/ALARM indicator and audible alarm;
5.3.2 The DVOR/DME RCSU shall be housed in a cabinet suitable for installation on either desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for			5.3.1.4	Alarm silence control with indicator;
desktop or rack in the Technical Control Room at ATC tower. 5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave ling (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for			5.3.1.5	Alarm reset.
5.3.3 The DVOR/DME RCSU shall be connected via land line or the Microwave line (provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for		5.3.2	The DVC	DR/DME RCSU shall be housed in a cabinet suitable for installation on either
(provided by the AEROTHAI). 5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for the standby transmitter/transponder into dummy loads for the standard transmitter/transponder into dummy loads for t			desktop	or rack in the Technical Control Room at ATC tower.
5.4 Remote Status Unit (RSU) 5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for		5.3.3	The DV	DR/DME RCSU shall be connected via land line or the Microwave link
5.4.1 The status indicator shall be provided with audible alarm that installed in the control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for			(provide	d by the AEROTHAI).
control room at ATC tower. 5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment shall have at least the following functions for each equipment shall be main transmitter/transponder; 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for	5.4	Remo	te Status	Unit (RSU)
5.4.2 The RSU shall have at least the following features: 5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each e		5.4.1	The stat	tus indicator shall be provided with audible alarm that installed in the
5.4.2.1 Display the operating status of the DVOR/DME in case of DVOR/DME system 5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponder into dummy loads for the standby transmitter/transponder into dummy loads for the standby transmit			control	room at ATC tower.
5.4.2.2 Visual and audible alarm with an alarm silence control; 5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponders; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for		5.4.2	The RSU	shall have at least the following features:
5.4.2.3 Turn on/off switch for the status indicator. 5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment shal			5.4.2.1	Display the operating status of the DVOR/DME in case of DVOR/DME system;
5.5 Remote Monitoring and Maintenance Equipment (RMM) 5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponders; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for			5.4.2.2	Visual and audible alarm with an alarm silence control;
5.5.1 The RMM Equipment shall monitor and control equipment by TCP/IP or better. 5.5.2 The RMM Equipment shall have at least the following functions for each equipment shall have at least the following functions for ea			5.4.2.3	Turn on/off switch for the status indicator.
5.5.2 The RMM Equipment shall have at least the following functions for each equipment 5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponders; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for	5.5	Remot	te Monito	ring and Maintenance Equipment (RMM)
5.5.2.1 Selecting the main transmitter/transponder; 5.5.2.2 Turning on/off transmitters/transponders; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for		5.5.1	The RMN	M Equipment shall monitor and control equipment by TCP/IP or better.
5.5.2.2 Turning on/off transmitters/transponders; 5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for		5.5.2	The RMN	A Equipment shall have at least the following functions for each equipment:
5.5.2.3 Turning on the standby transmitter/transponder into dummy loads for			5.5.2.1	Selecting the main transmitter/transponder;
			5.5.2.2	Turning on/off transmitters/transponders;
testing purposes;			5.5.2.3	Turning on the standby transmitter/transponder into dummy loads for
				testing purposes;

	5.5.2.4 Bypassing the monitor;
	5.5.2.5 Resetting the alarm;
	5.5.2.6 Shutting down the station;
	5.5.2.7 Adjusting and displaying transmitter/transponder and monitor parameters.
5.5.3	The RMM Equipment shall be interfaced to DVOR/DME station via land line or TCP/IP
	network with the Microwave link (provided by AEROTHAI).
5.5.4	The communication for the RMM must be separated from that for the RCSU for
	redundancy propose.
5.5.5	The RMM Equipment shall be performed by Desktop Computer.
5.5.6	One (1) set of Desktop Computer shall be provided as part of the DVOR/DME
	RMM. The Desktop Computer Specifications are specified in clause 10.
5.5.7	The RMM Equipment software for remote monitoring and controlling the DVOR/DME
	equipment from anywhere shall be installed in the Desktop Computer. The recovery
	CD/DVD or any portable data storage devices for the RMM software shall be
	provided. The user's license for the software shall be provided for AEROTHAI.

6.	INTE	RSYSTEM CONNECTION		
	6.1 The DVOR/DME System shall be connected with RCSU (Provided by the contrac			
		and CCMS (provided by AEROTHAI) to send update information.		
	6.2	The DVOR/DME operation status shall be updated by Simple Network Management Protocol		
		(SNMP) over Ethernet port.		
	6.3 The Tenderer shall provide and detail the DVOR/DME-RCMS, CCMS information excha			
	6.4 The Contractor shall provide a list of all necessary standards documents and			
	Control Documents (ICDs) with regards to the DVOR/DME-RCMS and CCMS information			
		exchange.		

7.	SUP	UPPLEMENTS		
	7.1	Porta	ble Navi	gational Signal Analyzer (PNSA) [E]
		7.1.1	One (1) set of Portable Navigational Signal Analyzer shall be provided. They shall be
			used fo	r ground test of the ILS, VOR and Marker beacon. Each PNSA shall comprises:
			7.1.1.1	Receiver for Localizer, Glide Slope, VOR and Marker Beacon;
			7.1.1.2	Built-in rechargeable battery;
			7.1.1.3	Antennas for Localizer, Glide Slope and VOR;
			7.1.1.4	Battery Charger;
-			7.1.1.5	Antenna Pole;

	,		
			7.1.1.6 Accessories.
		7.1.2	The PNSA shall be designed for outdoor purpose with compact and weatherproof.
		7.1.3	All ILS/VOR channels shall be selectable.
		7.1.4	Performance analyzer of ILS Localizer, Glide Slope, Marker Beacon and VOR shall be
-			performed in accordance with ICAO Doc 8071 Vol. I.
		7.1.5	All parameters shall be printed out directly or export to the external portable storage
			media e.g. HD/USB drive or other devices in text format.
		7.1.6	PNSA shall be provided real time measurement data directly via RS 232 C or USB port
			or IP/Ethernet.
		7.1.7	PNSA shall be provided with the Interface Control Document (ICD) for extracting or
		<u> </u>	decoding the real time measurement data.
		7.1.8	Battery charger shall be operated on 220 VAC $\pm 15\%$, 50 Hz $\pm 5\%$ single phase or better.
	7.2	DVOR	Spare Parts
		7.2.1	One (1) set of DVOR spare parts shall be provided.
		7.2.2	The DVOR spare parts in 7.2.1 shall consist of one complete unit which is under single
			system configuration. The one complete unit shall consist of line replaceable module
			(LRM), printed circuit boards (PCBs), backplanes and RF switches (Coaxial relays), RF
			distribution units.
			Remark : "SINGLE" system configuration means "SINGLE" transmitter and "SINGLE"
			monitor.
	7.3	DVOR	Antenna Spare Part
		7.3.1	One (1) Set of carrier antenna spare part and Four (4) sets of sideband antenna
L			spare part shall be provided
		7.3.2	The carrier and sideband antenna spare parts shall consist of the antenna element,
			antenna cover, RF feeding cable and RF cable lightning protection kit.
	7.4	DME S	Spare Parts
		7.4.1	One (1) set of DME spare parts shall be provided.
		7.4.2	The DME spare parts in 7.3.1 shall consist of one complete unit which is under single
			system configuration. The one complete unit shall consist of line replaceable module
			(LRM), printed circuit boards (PCBs), backplanes and RF switches (Coaxial relays).
			Remark: "SINGLE" system configuration means "SINGLE" transmitter and "SINGLE"
			monitor.
			·

Version 1.0

7.5	DME Antenna Spare Part		
	7.5.1	One (1) set of DME antenna spare part shall be provided.	
	7.5.2	The DME antenna spare parts shall consist of the antenna, RF feeding cable and RF	
		cable lightning protection kit.	
7.6	RCSU and RSU Spare Parts		
		One (1) set of RCSU and RSU spare parts for DVOR/DME systems shall be provided.	
7.7	Doub	le LED obstruction lighting Spare Parts (in clause 3.5.12 and 4.4.4)	
		One (1) set of Double LED obstruction lighting equipment for DVOR/DME systems	
	ĺ	shall be provided as spare parts.	
7.8 The contractor shall provide manufacturer's certification for availability of spare		ontractor shall provide manufacturer's certification for availability of spare parts for	
	ten (10) year from the expiration of the warranty period.		
	The tenderer shall submit this certificates in the proposal.		

8.	TOC	TOOLS FOR INSTALLATION AND MAINTENANCE			
	One	(1) set shall provide. Each set comprises:			
	8.1	1 The contractor shall provide at least waveform analysis tools, thruline wattmeter, digital			
		multi-meter, portable RF power analysis, frequency counter and additional tools that			
		complies with manufacturer standard for DVOR/DME system installation, Maintenance			
		and hardware adjustment. The contractor shall provide list of recommend installation			
		and Maintenance tools from manufacturer.			
	8.2	Extension cards (if any) and cables as required for each module/ PCB of the DVOR and DME			
		shall be provided for maintenance.			
	8.3	Test cables, dummy loads, RF adapter kits and attenuation kits for transmitter calibration			
<u></u>		and flight inspection shall be provided.			
	8.4	Installation materials such as external and internal cablings, cable trays, cable ladder,			
		connectors, cable ties and conduits shall be provided.			
9.	TECH	INICAL DOCUMENTS AND TEST REPORTS [E]			
	The (Contractor shall provide the following documents:			
	9.1	One (1) set for hard copy and Two (2) DVD sets for mechanical and electrical DVOR/DME			
		drawings and whole network diagrams essential for installation, maintenance and			
		troubleshooting of the equipment, including such drawings as are needed to identify the			
		components and cable within the equipment or its sub units;			


	9.2	Two (2) sets for hard copy and Three (3) sets for DVD, of DVOR/DME installation and
		equipment instruction manuals, setting out in detail the procedures for operation, routine
		maintenance, troubleshooting of the equipment, test and alignment procedures, including
		schematics and inter-cabling diagrams;
Г	9.3	Two (2) sets for hard copy and Three (3) sets for DVD, of DVOR/DME component part
		lists which includes manufacturer part numbers or descriptions of any generic component
		level devices (ICs, transistors, capacitors, etc.) in each Line Replaceable Modules (LRMs)
		shall be provided for the propose of comparing for the generic devices with electronic
		component in the market in order to repair the LRMs after the warranty period.
	9.4	One (1) original and One (1) hard copies of Factory Acceptance Test (FAT) report shall
		be provided at the factory after the completion of FAT.
	9.5	One (1) original and Two (2) sets hard copies of Site Acceptance Test (SAT) report shall
		be provided at the site after the completion of the commissioning flight check.
	9.6	One (1) original and Two (2) sets hard copies of Function Unit Test (FUT) report shall be
		provided at the site before the completion of the installation.

10. DE	10. DESKTOP COMPUTER				
	Th	e Tende	erers shall provide the Desktop Computer including all attached devices that are		
installe	ed 1	for syst	em operation and monitoring. The Tenderers shall propose the technical		
specific	catic	ons of	Desktop Computer which comply with or are better than the following		
specific	catic	ons.			
10).1	All com	ponents shall be produced form the same manufacturer with permanent logo/		
		brand o	n products.		
10).2	All in or	ne computer		
10).3	Processo	or/ Chip set		
		10.3.1	≥ 4 Core or ≥ 8 Thread		
		10.3.2	Base clock frequency ≥ 3.2 GHz		
10).4	RAM			
	,	10.4.1	Technology – DDR3 or better		
		10.4.2	Capacity - ≥ 8 GB		
10).5	One (1)	Hard disk Drive		
			SATA or better Capacity - ≥ 2.0 TB or Solid State Device ≥ 240 GB		
10).6	One (1)	Optical Disc Drive		
			Internal DVD/RW Drive		

10.7	Graphic	Controller
		Built-in graphic or Dedicated graphic controller with ≥ 1 GB memory
10.8	One (1)	Display
		≥ 19 inches LED with resolution 1920 x 1080 pixels
10.9	Network	ting
		10/100/1000 Mbps Ethernet
10.10	One (1)	Keyboard and One (1) Mouse
		Each key shall be permanently printed with both Thai and English characters
10.11	Operation	on System/ Software
	10.11.1	Shall be installed with the Desktop Computer
	10.11.2	Capable of operating with the software of the proposed DVOR/DME System.
	10.11.3	Recovery DVD with a copyright shall be provided
10.12	The op	erating system and license which is suitable for compute operating shall be
10.13		set of Office table and chair which is suitable for computer operation shall be
	provide	
10.14	The Des	ktop Computer shall have a manufacturer branch office authorized representative
	in Thaila	and.
10.15	The DV) for software driver shall be provided with the product.

11. CONCEPTUAL DIAGRAM OF INTERSYSTEM CONNECTION AND COMMUNICATION

11.1 DVOR/DME Diagram for Betong Airport.



Note: Switch, Firewall, Microwave links, Fiber optics links, RCMS, CCMS, EMMC provided by AEROTHAI

APPENDIX A: LIST OF ABBREVIATIONS

Abbreviations	Full Name
°C	Degree Celsius
AC	Alternating Current
AEROTHAI	Aeronautical Radio of Thailand Ltd.
CCMS	Central Control and Monitoring System
cms	Centimeters
cw	Continuous Wave
dB	Decibel
DDM	Difference in Depth of Modulation
DME	Distance Measuring Equipment
DVOR	Doppler Very High Frequency Omni-directional Radio Range
EMMC	Electrical Monitoring and Management Center
FAA	Federal Aviation Administration
GHz	Giga Hertz
GS	Glide Slope
Hz	Hertz
HDPE -	High Density Polyethylene
ICAO	International Civil Aviation Organization
ICD	Interface Control Document
ILS	Instrument Landing System
lmax	Maximum Discharge Current
Intl	International
kVA	Kilo Volt Amp
kms	Kilometers
kHz	Kilo Hertz
MHz	Mega Hertz
MTBF	Mean Time Between Failure
МТВО	Mean Time Between Outage
mph	Mile per hour
μs	Microsecond
PABX	Private Automatic Branch Exchange

Abbreviations	Full Name						
PCB	Printed Circuit Board						
PMDT	Portable Maintenance Data Terminal						
PNSA	Portable Navigational Signal Analyzer						
PVNA	Portable Vector Network Analyzer						
RCMS	Remote Control and Monitoring System						
RCSU	Remote Control and Status Unit						
RF.	Radio Frequency						
RSC	Radio Frequency Rigid Steel Conduit Remote Status Unit Remote Monitoring and Maintenance						
RSU	Remote Status Unit						
RMM	Remote Monitoring and Maintenance						
SNMP	Simple Network Management Protocol.						
SDM	Sum in Depth of Modulation						
STS	Static Transfer Switch or one (1) Source Transfer Switch						
Uc	Maximum Continuous Operating Voltage						
Up	Voltage Protection Level						
UHF	Ultra High Frequency						
UPS	Uninterrupted Power Supply						
USB	Universal Serial Bus						
VAC	Voltage of Alternating Current						
VOR	Very high frequency Omni-directional Radio Range						

APPENDIX B: Figure C-20 of [ANNEX 10 / Vol. I / Attachment C / Paragraph 7.2.1].

The protected coverage of DME/N shall be determined by using Figure C-20 of [ANNEX 10/Vol. I / Attachment C/Paragraph 7.2.1]. The propagation loss for paths without obstructions uses the IF-77 propagation model.




Figure C-20 of [ANNEX 10 / Vol. I / Attachment C / Paragraph 7.2.1]. Necessary EIRP of DME transponder to achieve a power density of $-89~\mathrm{dBW/m^2}$ (at airborne receiver) as a function of height above and distance from the DME. The above figure is based on the following example,

1. Airborne receiver sensitivity

: -120 dBW

2. Transmission line loss, mismatch loss,

: +9 dB

antenna polar pattern variation with respect to an isotropic antenna

3. Antenna height

: +5 m (17 ft) AGL over flat terrain

4. Power density required at antenna

: -111 dBW

Remark: Minus 111 dBW at the antenna corresponds to minus 89 dBW/m² at the mid-band frequency.

Project Name		
Procurement for	Retona	DVOR/DMF

Date

February 21, 2019

Version 1.0

APPENDIX C: Location

DVOR/DME	Location
- Betong Airport	5 47' 7.71" N
	101 8 ' 38.64" E (ค่าพิกัดในเบื้องต้น)

GUIDELINE FOR "Bill of Materials and Services"


ITEM	Description	Quantity	Remark	Reference Clause
		EQUI	PMENT	
	DVOR Equipment	1		3
1	DME Equipment	1		4
2	DVOR Antenna System	1	Complete antenna system including Antenna mast, RF surge protection,	3.3, 3.4
	DME Antenna System	1	obstruction lighting	4.4
3	Counter Poise Edge Monitor Antenna System	2	Due to difficult terrain at Betong Airport, At least two (2) Counterpoise edge Monitor (including RF surge protection)	3.5.11
4	Thruline (line sections) with plugin elements for carrier power reading	1		3.3.10
·	RF power meter for thruline (carrier)	1		3.3.10
	Thruline (line sections) with plugin elements for sideband power reading	4		3.4.4
	RF power meter for thruline (sideband)	4		3.4.4
5	DVOR/DME Lightning Protection System	1		2.15
6	Double LED OBS Light for DME	1	Including photo switch	4.4.4
7	DVOR LCU Computer	1		5.1.4
	DME LCU Computer	1		5.2.4
	DVOR/DME RMM Computer	1		5.5.6
	Table and Chair for both LCU computer	1		10.13


ITEM	Description	Quantity	Remark	Reference
I t CIVI			·	Clause
		SPARE	PART	
8	Spare Part for DVOR	1	one complete unit which is under	7.2
•	Equipment		single system configuration	
	Spare Part for DME	1	one complete unit which is under	7.4
	Equipment		single system configuration	
	Spare Part for DVOR carrier	1	Spare parts shall consist of the	7.3.1
	antenna		antenna element, antenna cover,	
			RF feeding cable and RF cable	
			lightning protection kit.	
	Spare Part for DVOR	4	Spare parts shall consist of the	7.3.1
	sideband antenna		antenna element, antenna cover,	
			RF feeding cable and RF cable	
			lightning protection kit.	
	Spare Part for DME	1	Spare parts shall consist of the	7.5
	antenna	·	antenna, RF feeding cable and RF	
	· .		cable lightning protection kit.	
	Spare Part for RCSU	11	100 % Whole unit	7.6
	Spare Part for RSU	1	100 % Whole unit	7.6
	Spare Part for Double LED	1		7.7
	OBS Light			<u> </u>
10	List of recommend	1		8.1
	installation and			
	Maintenance tools	·		
	Portable Navigational	1		7.1
	Signal Analyzer (PIR)			
	Waveform analysis tools	1	·	8.1
	(Oscilloscope)			
	Thruline wattmeter	1	include Directional Coupler	8.1
	Digital multi-meter	1		8.1
	Portable RF power analysis	1		8.1
	Frequency counter	1		8.1
	Local Network Equipment	Recommend		6

February 21, 2019

Version	1	٥.
version		.U

ITEM	Description	Quantity	Remark	Reference
				Clause
	External Connector	Recommend		2.13.7
	Other equipment	Recommend		
	Accessories	Recommend		
		DOCÚME	ENTS	
11	Mechanical and electrical	1 (H), 2 (S)	"H" Stand for Hard Copy	9.1
	DVOR/DME drawings and		"S" Stand for Soft copy	
	whole network diagrams		•	
	DVOR/DME installation and	2 (H), 3 (S)		9.2
	equipment instruction			
	manuals			
	DVOR/DME component	2 (H), 3 (S)		9.3
	part lists			
	ICDs for DVOR/DME	1		6.4





สารปัญเกน แมกในคลจำแห่งๆที่สาขาง รายการใต แนกเห็น แนกหลังกา รูปดี ค.ศ. รูปดี 8-8 แน่การีน และเปลาหรังก

7-AR-01 7-AR-02 7-AR-03

guin a meguina 2 guina 1 meguina 4 guina 3 meguina 4 unaerestas muna unariesta

7-AR-04 7-AR-05 7-AR-06

umaranyja i go เล้า หนับขอบขอบเม ะนามแรกสาราชานิโด 1 คร นรถเหลาะหนังใค 2 นงการสาขาที่ใน


> 7-AR-10 7-AR-11 7-AR-12 7-AR-13

7-AR-07 7-AR-08 7-AR-09

PHALLIN

สารปัญแบบ

งานลถานโดยกรรม



สารนักแบบ

			_	_			_				_								
รายคะเป็นค	สำคัญแรม สัญผักรณ์ และจอนของกน	NUMBER SINGE LINE DIACKAN WE LOAD SCHEDULE	WANTERSON TRANSPORTER OF THE PROPERTY OF THE	นรถแมคณีสากสิตติ์สุดใหาณ์กานใหมายการ	ระบารมรับอาการเครียก และจบบโลกที่เกิดเป็นเกิดเรียกเกรมการส	THE GOOD SHOWN OF THE PROPERTY OF	(1) эконяшкого ищкамерая экскогого племетиля	(2) эзо-изимо инменения окимоно посинентия	equirare year unum	กละครุงมนุโรงสารการอยู่ครุงมมาเลยกากก	nauspyssendergevaagspagsuseregel	(i) กลบสุดกระบานิสเทศเรของเกษตลงแบบสามารถ	(z) navegyszenbemennagysygnezerowannygik	WANT YAR STORAGE TANK WIR FUEL DAY WANT	AND RESIDENCE WAS NAMED TRANSPORTED FOR THE PROPERTY.	<u> </u>	000H 131L00 กิเภสทั้งส		
เลขที่นาม	7-EE-01	7~EE-02	7-EE-03	7-EE-04	7-EE-05	7-15-08	7-EE-07	7-E-08	7-EE-00	7-EE-10	7-EE-11	7-EF-12	7-EE-13	7-E-14	91-33-4	91-II-L	41-33-4		
und	1	2	3	,	2	9	7	8	f	10	11	12	13	*	15	16	17		

ขอบเขตงานติดตั้งระบบไฟฟ้าในอาคารสถานี OVOR

ขอนเจลงานดิตตั้งระบบให้ฟ้าในอาการสถานี DVOR ประกอบด้วยรายการดังค่อไปปี้

1. ลิลตั้งเมื่อนปลง (TRANSFORMER : TF3) พร้อมรับสื่อมหม้อนปลง บ่อพักสาย และสายแบ่ให้ฟ้าแรงสู่ประจำคำหรับสถาบี OVOR

- 2. ติดตั้งสายสัญญาณกาบคุม (AP CONTROL LINE) เชื่อมค่อกับ MDF ที่ขอบังคับการบิน หร้อมปอพักสาข
- พิดพังระบบเกรื่องยนส์ขนาด 50kVA หรือมอุปกรณ์ประกธบการทำงานของเครื่องยนท์ให้แก่


· ISOLATING SWITCH


- FUEL TANK ขนาดไม่น้อยกว่า 200 ลิตร


- Oil TANK sunsliniesoch 1,500 Bas


- FUEL PUMP WAS FUEL PUMP CONTROL PANEL

- คิดตั้งระบบให้สำนผงสว่าง เด้ารับไฟฟ้า เต้ารับไทรศัพท์ และเด้ารับคอมพิวเตอร์ตามตำแหน่งที่ระบุ
- คิดหังสาบป้อนสำหรับเครื่องบรับอากาศตามดำแหน่งที่ระบุ
- 6. ตั้งค้าบนุกระบบใหห้ก (SAFETY SMITCH, MDB, LOAD PANEL) ผู้ที่กะบบใหห้หที่ (TELEPHONE CABNET) และผู้ RACK สำหรับ NETWORK SWITCH (ผู้ว่าค้างตัพมา NETWORK SWITCH) หรือมาจะค้าสะบดามค้ามหน้าที่ระบุ
- 7. คิดที่จะบบ UPS หา้อมอุปกรณ์ STS และทู้ DISTRBUTTON BOARD, LOAD PANEL ที่เกี่ยวจ้อง
- คิดตั้งระบบการต่อลงดินของอาคารสถาปี 0v0R
- 9. ติดตั้งระบบป้องกับฝ้าผ่า (LIGHTNING ARRESTER) และเชื่อมค่อเข้ากับระบบราเสายติเกยจอาการ DVOR
- คิดหั้งกรระบบไฟฟ้าและระบบผื้อการประกอบอาการอื่น ๆ ที่เกิดหนืองกับระบบไฟฟ้าของอาการนี้ เพื่อให้การใช้งานระบบไฟฟ้า ของอาการกานารถใช้งานได้ถูกต้องครบต้านงานบุรณ์









8	LOAD PANEL BOARD NAME:	MD8-DVOR	*					LOCATION:		000	ОVORВПИТ ОМО	SW)
מוצנו	CIRCUIT CAPACITY:	,						MOUNTINGS			Waii Mounted	pezuno
œt.	LOAD DESCRIPTION	Ĺ	(AV) CAVO)			9		CABLE		NOS	CÓNDUT	RENDAR
ē		Phase-A	Phase-B	Phase-APhase-BPhase-C	ΑŢ	*	POLE	3235	TYPE	326	1 TYPE	
-	0-41	5,550	5,620	4,600	8	8	E	4x6.0/1x4.0	(ECO)	.2/1	BMI	
~	UPSI	3,300	3,300	3,300	ន	ğ	EII.	4x4.0/1x2.5 IECO1	IEC01	.Z/I		
-	UPS2	3,300	3,300	3,300	2	8	ĩ	4x4.0/1x2.5 IEC01	10031			
7	SPARE	1,500	1,500	1,500	20	100	3					
		13,650	13,630 11,720 12,700	12,700			-		MAIN	MAINCABLE	Ì	4x35 NYY
5	ייסועל רמשעברובת נמעת		40,070		Š	DEMORNIC LONDS:	ä	40,070	CONT	CONDUITE	_	WIREWAY
34.4	MAIN: MCC890AT/100AF3P.IC>-15KA	IC>=15 KM							fee g	FEED FROM:	33	SAFETY SWITCH

		230/4	9E VOO	hELEC	뎚	9	AD S	230/400V 3Ph ELECTRICAL LOAD SCHEDULE			۳.	5
OWD	LOAD PANEL BOARD NAME:	041						LOCATION:		DVG	DYOR BUILDING	SHIL
ORCI	ORCUIT CAPACITY:	22						MOUNTING			Wolle	Wall Mounted
8	LOAD DESCRIPTION	ı	(AV) CAD I			8		CABLE		נסאו	CONDUIT	жемав
Š		Phase-A	B-ase4d	Phase-Aphase-Ephase-C	AT	¥	POLE	SIZE	TYPE	37/5	TYPE	
н	LIGHTING	1,750			2	ğ	-	2×2.5	EC01	1/1	ENT	
-	RECEPTACLE		1,520		2	8	-	2x2,5/1x2,5	EGN	173	EMI	
5	EMERGENCYLIGHT			909	9	욢	-	242.5/11/2.5	15001	1/5.	EMI	
-	FUEL PUMP CONTROL	300			91	8	-	2#2.5/1x2.5	16531	1/2.	Z	
۰	SPARE		1,000		2	8	1					
=	SPAKE			1,000	2	188	-					
~		1,500										
-	4/C-01 (36,0008TU)		1,500		20	200	m	4x4/1x2.5	ğ	3/4	EMCI	
				1,500								
ъ		1,500										
2	A/C-02 (35,000BTU)		200		2	91	3	4x4/1x2.5	103	3/4-	¥	
11				1,500								
		5,550	5,620	4,600	-		-		NAN	MAIN CABLE:	4×6	4×6/1×4.0 IECO1
2	T COMMERCIAN COMP		15,770		Ě			11,270	CON	CONDUIT:		WIREWAY
2	MAIN: MCGE30AT/100AF3P.IC10KA	DOT	ı						(CEED)	FEED FROM:	_	MDB-DVOR
1		l	l	l	l	l	l			l	l	۱

Dellani umqan m.2006

		230/4	900/39	h ELEC	E S	2	ADS	230/400V 3Ph ELECTRICAL LOAD SCHEDULE				
ĝ	LOAD PANÉL BOARD NAME:	UP-01, UP-02	20 di					LOCATION:		ava	DVOR BUILDING	ING
CIRCU	CIRCUIT CAPACITY:	27					-	MOUNTINGS			Wall Mounted	punted
ğ	LOAD DESCRIPTION	1	(AV) OVO			8		CABLE		NOO	CONDUIT	REMARK
Ä		Phase-A	Phase-A'Phase-B'Phase-C	Phased	Į,	2	POLE	3215	TYPE	312E	TRPE	
-	SPARE	1,200			42	9	-					
~	SPARE		1,200		36	8	-					
~	SPARE			1,200	22	훮	-					
~	SPARE	1,200			16	õ	-					
0	SPARE		1,200		16	<u>10</u>	-					
ä	SPARE			1,200	15	ã	-					
7	SPACE											
4	SPACE											
9	SPACE		-									
	SPACE											
2	SPACE											
12	SPACE											
	Carl Control Con	2,400	2,400	2,400	ž				MAIN	MAINCABLE	4x4/	4x4/1x2.5 IECD1
į	COLUMNICATION		2,200		5	2		7,200	S	CONDUIT:	>	WIREWAY
MAR	MAIN: MCCB20AT/100AF3P.1C>=10KA	C~10 KJ	ارا						FEED	FEED FROM:	<u>د</u>	5151, 5152



SINGLE LINE DIAGRAM

